





HP Pavilion home PC




© 2004 Hewlett-Packard Development Company, L.P.
Printed in
www.hp.com






5 9 9 1 - 8 1 6 6



1 Keyboard and Mouse 鍵盤和滑鼠





Wireless Option Please refer to the setup instructions located in your mouse/receiver box.

無線選購裝置
請參閱滑鼠/接收器盒內的安裝指示。





OR
或


2 Monitor Refer to setup instructions that came with your monitor. 顯示器 請參閱顯示器隨附的安裝指示。




3 Speakers Refer to setup instructions that came with your speakers. 喇叭 請參閱喇叭隨附的安裝指示。




4 Power Connection 電源連接




5 Modem / LAN 數據機 / LAN




OR
或




6 Power On 電源開啓



NOTE: Your components and connection locations may vary by model.
注意事項：您的組件與連接位置可能會因型號而異。



- | | |
|--|-------------------------------------|
| A — Optical drives | A — 光碟機 |
| B — Optical drive Eject buttons | B — 光碟機的「退出」鈕 |
| C — Floppy drive | C — 軟碟機 |
| D — Card reader | D — 讀卡機 |
| E — Headphones | E — 耳機 |
| F — Audio Line In | F — 音訊音源輸入孔 |
| G — Microphone | G — 麥克風 |
| H — FireWire (IEEE 1394) port | H — FireWire (IEEE 1394) 連接埠 |
| I — USB 2.0 ports | I — USB 2.0 連接埠 |
| J — Door | J — 外蓋 |
| K — On button with Indicator | K — 主機開關按鈕及指示燈 |
| L — Hard drive Activity light | L — 硬碟作業指示燈 |



- | | |
|------------------------------------|-----------------------------|
| A — Power LED | A — 電源 LED |
| B — Voltage selector | B — 電壓選擇開關 |
| C — Power Cord connector | C — 電源線插孔 |
| D — PS/2 Mouse connector | D — PS/2 滑鼠接頭 |
| E — PS/2 Keyboard connector | E — PS/2 鍵盤接頭 |
| F — Serial port | F — 序列埠 |
| G — Parallel port | G — 並列埠 |
| H — VGA Monitor port | H — VGA 顯示器連接埠 |
| I — 4 USB 2.0 ports | I — 4 個 USB 2.0 連接埠 |
| J — LAN (Ethernet) | J — LAN (乙太網路) |
| K — Microphone connector | K — 麥克風插孔 |
| L — Audio Line Out | L — 音訊音源輸出孔 |
| M — Audio Line In | M — 音訊音源輸入孔 |
| N — Modem (Line In RJ-11) | N — 數據機 (線路輸入 RJ-11) |
- Select models only:**
- | | |
|--|-------------------------------------|
| O — Digital Audio In | O — 數位音訊音源輸入孔 |
| P — Digital Audio Out | P — 數位音訊音源輸出孔 |
| Q — FireWire (IEEE 1394) port | Q — FireWire (IEEE 1394) 連接埠 |
| R — Side speaker port | R — 側置喇叭連接埠 |
| S — Rear speaker port | S — 後置喇叭連接埠 |
| T — Center speaker/subwoofer port | T — 中置喇叭/重低音喇叭連接埠 |

僅限於部分型號：

- O** — 數位音訊音源輸入孔
- P** — 數位音訊音源輸出孔
- Q** — FireWire (IEEE 1394) 連接埠
- R** — 側置喇叭連接埠
- S** — 後置喇叭連接埠
- T** — 中置喇叭/重低音喇叭連接埠